

Declaration of Conformity as per Directive 97/23/EC and Manufacturer`s Declaration as per Directive 98/37/EC

The manufacturer	Pfeiffer Chemie-Armaturenbau GmbH, 47906 Kempen, Germany
declares that:	PFA/PTFE-lined control valves Series 1a, Series 1b, Series 1c, Series 1z, Series 6a and Series 8a, with PTFE bellows seal or diaphragm seal <ul style="list-style-type: none"> • with pneumatic/electric/hydraulic actuator • with free shaft end for subsequent mounting of an actuator
<ol style="list-style-type: none"> 1. The valves are pressure accessories within the meaning of the Pressure Equipment Directive 97/23/EC and conform with the requirements of this Directive, 2. The valves are not complete machinery within the meaning of the Machinery Directive 98/37/EC, but meet the relevant requirements of this Directive, 3. They may only be operated observing the operating instructions <BA01a-01_EN> delivered together with the valve. <p>The commissioning of these valves is only permitted after the valve has been installed from both sides in the pipeline and a risk of injury can be ruled out.</p>	

Applied standards:

AD 2000 Regulations DIN-EN 292-2000	Regulations for pressurized valve body parts Safety of Machinery, Part 2: Technical requirements
--	---

Type designation and technical features:

Pfeiffer data sheets <TB01a_EN, TB01b_EN, TB01c_EN, TB01z_EN, TB06a_EN and TB08a_EN> <i>NOTE: This Manufacturer's Declaration applies to all valve types listed in this catalog.</i>

Applied conformity assessment procedure:

Conforming to Annex II of the Pressure Equipment Directive 97/23/EC, Module H
--

<i>Name of notified body:</i>	<i>Identification number of the notified body:</i>
TÜV Rheinland Service GmbH Am Grauen Stein 51101 Köln Germany	0035

These Declarations become invalid when modifications are made to the control valves and/or assemblies that affect the technical data of the control valve or the <Intended use> described in section 1 of the operating instructions, and considerably change the valve or an assembly delivered with it.

Kempen, 2. January 2008

Lorenz Stolzenberg, Managing Director

These Declaration of Conformity and operating instructions have been generated electronically and are legally binding without signature

Operating instructions


Control valve with PFA/PTFE lining actuated

Contents

0	Introduction	3
1	Intended use	3
2	Safety instructions	3
2.1	General safety instructions	3
2.2	Safety instructions for the operator	4
2.3	Particular hazards	4
2.4	Designation of the control valve	5
3	Transport and storage	5
4	Installation in the pipeline	6
4.1	General	6
4.2	Installation instructions	6
5	Pressure check in pipeline section	8
6	Standard operation and maintenance	8
7	Troubleshooting	9
8	Further information	10

0 Introduction


These instructions are designed to assist the user during installation, operation and maintenance of PFA/PTFE-lined control valves from the **Series 1a, Series 1b, Series 1c, Series 1z, Series 6a and Series 8a**. These instructions apply only to the control valve itself. In addition, refer to the instructions of the mounted actuator.

 Note	<p>The WARNING and CAUTION notes must be strictly adhered to. Otherwise this may lead to personal injury and equipment damage and the manufacturer's warranty may become void. Please contact the manufacturer if you have any queries, see section 8 for contact address.</p>
--	---


1 Intended use

After installing the valve in the pipeline and connecting the actuator to the control equipment, these control valves are designed exclusively for shutting off or controlling media (often corrosive) within the permissible pressure and temperature ranges.

The permissible pressure and temperature ranges for these control valves are specified in the data sheets <TB01a_EN, TB01b_EN, TB01c_EN, TB01z_EN, TB06a_EN and TB08a_EN>.

 Danger	<p>Do not operate a control valve when its permissible pressure/temperature rating is not sized for the operating conditions specified in the data sheets <TB01a_EN, TB01b_EN, TB01c_EN, TB01z_EN, TB06a_EN and TB08a_EN>.</p> <p>Failure to follow these safety precautions may result in personal injury and can damage equipment installed in the pipeline.</p>
--	---

Observation of conformity with the Directive 94/9/EC.

 Note	<p>Pfeiffer valves do not have their own potential ignition source according to the risk assessment in the rare incident of an operating fault in accordance with DIN EN 13463-1:2000 and therefore do not fall within the scope of the Directive 94/9 EC. Relating to this directive, CE marking is not permissible.</p> <p>The integration of valves into the equipotential bonding of a plant applies to all metallic parts in hazardous areas regardless of the directive.</p> <p>Valves with plastic lining (PFA, PTFE) in applications with chargeable media have to be lined with conductive plastic lining with a surface resistance less than 1 Gigaohm (10^9 Ohm) in accordance with paragraph 7.4 of DIN EN 13463-1:2001.</p>
--	---

Observe the restrictions in the specified data sheets if the control valve is intended for throttling services.

Observance of section 2 <Safety instructions> is presumed for the Intended use.

2 Safety instructions

2.1 General safety instructions


For control valves, the same safety regulations apply as for the pipelines in which they are installed, as well as for the control equipment connected to the actuator. These instructions only specify those safety instructions which need to be additionally observed concerning control valves.

Additional safety instructions are specified in the instructions for the actuator assemblies.

2.2 Safety instructions for the operator






The manufacturer does not assume any responsibility. Therefore, on using the control valve, make sure the following instructions are observed:

- ⇒ The valve is to be used only for its intended use as described in section 1.

	<p>Preventing misuse of the control valve: It is especially important to make sure that the selected lining for wetted parts in the control valve is suitable for the media used as well as the prevailing pressures and temperatures.</p> <p>Warning Failure to follow these safety precautions may result in personal injury and can damage equipment installed in the pipeline. The manufacturer does not assume any final responsibility.</p>
---	---

- ⇒ Make sure that the pipeline and control equipment have been installed correctly and are checked at regular intervals. The valve body wall thickness must be designed to take into account an additional load F_z in the usual order ($F_z = \pi/4 \cdot DN^2 \cdot PS$) for a correctly sized pipeline.
- ⇒ The valve needs to be connected correctly to the pipeline and to the control equipment.
- ⇒ Control valves that are operated at temperatures greater than +50°C or lower than -20°C must be protected, together with the pipeline connections, against being touched.
- ⇒ Make sure the usual flow velocities are not exceeded in continuous service in this pipeline. Exceptional operating conditions such as oscillations, water hammering, cavitation and large proportions of solid matter in the process medium, especially abrasive, must be clarified beforehand with the manufacturer.
- ⇒ An actuator unit mounted subsequently onto the valve must fit the control valve properly and its final positions, especially the closed position, need to be correctly adjusted.
- ⇒ The valve should only be operated and serviced by personnel appropriately qualified for pressurized pipelines.

2.3 Particular hazards






 Danger	Prior to removing the control valve from the pipeline, relieve pressure entirely in the pipeline to ensure the process medium cannot escape uncontrollably from the pipeline.
 Warning	Should it be necessary to remove a control valve from the pipeline, process medium may escape from the pipe or out of the control valve. In the case of process media that can damage health or are dangerous, drain the pipeline completely before removing the control valve from the pipeline. Take special care concerning any remaining media that may still be in the pipeline or have collected in the cavities of the valve.
 Warning	Only unscrew or loosen any screws or bolts connecting the body parts after the valve has been removed from the pipeline. Tighten the screws on reassembly with a torque wrench according to the instructions <EB01a_EN, EB01b_EN, EB01c_EN, EB01z_EN, EB06a_EN or EB08a_EN>.
 Warning	<i>For control valves intended for dead-end service:</i> During standard operation, in particular, with gases or hot and/or dangerous media, mount a blank flange at the free end connection or ensure that the control valve is properly protected against unauthorised operation.
 Warning	If a control valve used for dead-end service must be opened in a pressurized pipeline, special care must be taken to ensure that any process media escaping under pressure does not cause any damage. Take into consideration that in most cases the process medium is a dangerous substance!

- ⇒ Make sure, in particular, that the plastic-lined facings of the flanges intended to connect the valve in the pipeline are not damaged through mechanical or other influences. Do not stack control valves!
- ⇒ As a rule, control valves are delivered in the completely closed position. Store the valves in the condition they were delivered in. Do not operate/activate the actuating device.



4 Installation in the pipeline

4.1 General


The same instructions apply for installing the control valves in the pipeline as for connecting pipes and similar pipeline equipment. The following instructions additionally apply for control valves. Also observe section 3 for transporting the control valve to the point of installation.

 Caution	<i>The valve is lined with PTFE/PFA:</i> Handle with special care and follow the instructions for flange connection.
 Note	<i>The facings of the valve body are lined with plastic.</i> If additional flange gaskets are used, we recommend using gaskets made of PTFE. The mating flanges must have smooth facings. Contact the manufacturer if you intend to use other flange forms.
 Warning	<i>The actuating device is set for the operating data specified in the order.</i> Do not alter the settings for the final positions OPEN and CLOSED without the manufacturer's prior consent.
 Warning	If an actuator unit has been mounted subsequently, torque, direction of rotation, operating angle as well as the final positions OPEN and CLOSED must be adapted to the control valve. Failure to follow these safety precautions may result in personal injury and can damage equipment installed in the pipeline.
 Warning	<i>Only for control valves with electric actuator:</i> Make sure that the actuator is switched off in the CLOSED position by the torque switch's signal . In the OPEN position, the actuator must be switched off by the limit switch's signal <i>See the instructions for the electric actuator for further details.</i>


The following warnings are to be observed for actuators:

 Warning	<i>Actuators are not designed to be used as step-ladders:</i> Do not apply any weight/load to the actuators. This can damage or destroy the control valve.
 Warning	<i>Actuators that weigh more than the control valve:</i> Support any actuator which due to its size and/or mounting situation would otherwise cause the valve to bend under the load.


4.2 Installation instructions

 Caution	<i>The lined surface of the valve must be specially protected before/during installation:</i> Transport the valve in its original packaging right up to the point of installation. Remove packaging first at the point of installation.
---	--

- ⇒ Check valve and actuator for signs of damage that may have occurred during transportation. Do not install a damaged control valve or actuator.
- ⇒ Make sure that only control valves are installed when their pressure rating, end connections and face to face dimensions match the conditions of application. See the designation of the control valve.

 Danger	<p>Do not install a control valve if its permissible pressure/temperature ranges do not apply to the operating conditions. The limits of application are marked on the valve, see section 2.4 <Designation>. The permissible range is determined in section 1 <Intended use>.</p> <p>Failure to follow these safety precautions may result in personal injury and can damage equipment installed in the pipeline.</p>
--	--

- ⇒ The connecting specifications for the actuator unit must match those of the control equipment. See nameplate(s) on the actuator unit.
- ⇒ Make sure the end connections of the pipeline are aligned with the control valve's end connections and their ends have parallel planes. Connecting flanges that are not parallel can damage the PFA/PTFE lining during installation!
- ⇒ Prior to installation, carefully clean the valve and the connecting section of the pipeline from dirt, especially hard foreign material.
- ⇒ Make sure, in particular, that flange facings (and any flange gaskets) are free from any dirt prior to installation.
- ⇒ On inserting the valve (and flange gaskets) into a ready mounted pipeline, keep a certain clearance between the pipeline ends to ensure that all facings (and gaskets) remain undamaged.

 Caution	<p>Tighten the flange bolts evenly and in a criss-cross pattern in at least three steps.</p> <p>Tighten all flange bolts using the torques specified in Tables 2 or 3. Use a torque wrench to ensure that the torque specified is reached, yet not exceeded.</p>
---	--


DN [mm]	25	40	50	80	100	150
MA [Nm]	25	50	60	65	75	140

Table 2 – Flange torques for DIN flanges

Size [inch]	1"	1 1/2"	2"	3"	4"	6"
MA [Nm]	15	30	40	65	50	100

Table 3 – Flange torques for ANSI flanges

- ⇒ The valve can be installed in any position. However, if possible, the actuator should not be located directly underneath the control valve.
- ⇒ Make sure the arrow on the valve body corresponds with the direction of flow in the pipeline.

 Note	<p>In special cases, it may be necessary for the valve to be tightly shut against the direction of flow. The installation in such special cases must be determined by the operator of the pipeline (e.g. to protect a pump).</p>
--	---

- ⇒ The associated instructions apply for connecting the actuator unit to the control equipment.
- ⇒ After completing installation, carry out a function check using the signals issued by the control equipment. The valve must open and close properly corresponding with the control signals. Any function errors that are recognized must be remedied before commissioning. See also section 7 <Troubleshooting>.



Warning

Control commands that are not carried out correctly **may result in personal injury and can damage equipment installed in the pipeline.**

5 Pressure check in pipeline section

The pressure check of valves has already been carried out by the manufacturer.
To check the pressure of a section of pipeline with installed valves, the following points must be observed:

- ⇒ Carefully flush newly installed pipes to remove any foreign material.
- ⇒ **Valve OPEN:** The test pressure should not exceed the value **1.5 x PN** (see nameplate).
- ⇒ **Valve CLOSED:** The test pressure should not exceed the value **1.1 x PN** (see nameplate).


If a valve leaks, proceed as described in section 7 <Troubleshooting>.




6 Standard operation and maintenance


- ⇒ Due to the fact that PTFE/PFA plastic facings have a tendency to flow, we strongly recommend to check flange bolt torques as specified in section 4.2 after commissioning and the normal operating temperature has been reached.
- ⇒ Operate the valve/actuator unit over the control equipment signals.
Control valves delivered with the actuator already mounted are precisely set and should not be readjusted.
- ⇒ The shaft is sealed with a PTFE bellows seal and does not require any maintenance.
- ⇒ Normal manual force is sufficient to operate the manual override on the actuator (if required). It is not permissible to use extensions to increase the operating torque.
- ⇒ Regular maintenance work on the control valves is not necessary.
Control valves with bellows seal or diaphragm are equipped with a leak-off connection (e.g. 1/4") between bellows seal / diaphragm and the external shaft seal which allows you to check whether the bellows seal or diaphragm are leaking.
- ⇒ If a valve leaks, proceed as described in section 7 <Troubleshooting>.

7 Troubleshooting

Observe the safety instructions listed in section 2 on troubleshooting.

 Warning	To remove a valve from a pipeline containing dangerous media and to take it out of the plant: Decontaminate the valves properly first.
---	--

Type of fault	Action to be taken	Comment
Leak at the connection to the pipeline	<p>Tighten flange bolts.</p> <p> Caution: The permissible tightening torque of the flange bolts is restricted. See table 2 or 3 in section 4.2 <Installation instructions>.</p> <p><i>If the medium leaks out at the flanges of the lined valve:</i> Retighten the flange bolts using the torque specified in Table 2 or 3 in section 4.2 <Installation instructions>. If necessary, the torque may be increased by max. 20 %.</p> <p><i>the medium leaks out at the flanges even after tightening the flange bolts:</i> Unscrew the flange bolts and remove the valve (on doing so, observe the instructions in section 2.3 <Particular hazards>). Check the parallel planes of the flanges and, if necessary, correct them. Also check the facing of all the flanges. If the plastic lining is damaged, replace it together with the associated flange gasket.</p>	<p>Note 1: <i>When ordering spare parts, include all the specifications listed in the valve designation. Only use original parts from Pfeiffer.</i></p>
Leak at the shaft seal	<p><i>If medium leaks out at the leak-off connection:</i> Remove the valve (observing the instructions in section 2.3 <Particular hazards>), dismantle the valve and replace the bellows seal or diaphragm. Contact Pfeiffer for spare parts and necessary instructions.</p> <p><i>If with the option „adjustable stuffing box“ the medium escapes at the stuffing box:</i> This version does not have a leak-off connection on the bonnet. The backup stuffing box is not gas tight from around 2 bar in the delivered state. This is reached by 3 mms of postset way of the security stuffing box sealed with red varnish.</p> <p>If the valve leaks at the stuffing box, the bellows is defective.</p> <p> Caution! All necessary safety measures must be taken to avoid any possible accidents. Always take into account that you are nearly always dealing with dangerous medium.</p> <p>Tighten the stuffing box.</p> <p> Caution! The valve no longer leaks, however, it should be repaired as quickly as possible, as there is no primary sealing. The sealing through the stuffing box should only be for a short period.</p> <p>Remove the valve (observing the instructions in section 2.3 <Particular hazards>), dismantle the valve and replace the bellows seal. Contact Pfeiffer for spare parts and necessary instructions.</p>	<p>Note 2: <i>If, after removing the valve from the pipeline, it is found that the PFA/PTFE lining is not sufficiently resistant to the process medium, select parts made of a suitable material.</i></p>
Leak at the connection between valve body parts	<p>For the permissible tightening torque to retighten the body halves of the valve, see Pfeiffer repair instructions <EB01a_EN, EB01b_EN, EB01c_EN, EB01z_EN, EB06a_EN or EB08a_EN>.</p> <p><i>If the valve still leaks:</i> Replace the flange gasket and/or valve.</p>	

<p>No tight shut-off when the valve is closed</p>	<p>Remove the valve (observing the instructions in section 2.3 <Particular hazards>) and check it.</p> <p><i>If the valve is damaged:</i> If it must be repaired, remove the valve, observing section 2.3 <Particular hazards>. Contact Pfeiffer for spare parts and necessary instructions.</p>	<p>Note 1: <i>When ordering spare parts, include all the specifications listed in the valve designation. Only use original parts from Pfeiffer.</i></p> <p>Note 2: <i>If, after removing the valve from the pipeline, it is found that the PFA/PTFE lining is not sufficiently resistant to the process medium, select parts made of a suitable material.</i></p>
<p>Malfunction</p>	<p>Check actuator unit and control signals</p> <p><i>If actuator and control equipment are in order:</i> Remove the valve (observing the instructions in section 2.3 <Particular hazards>) and check it.</p> <p><i>If the valve is damaged:</i> If it must be repaired, remove the valve, observing section 2.3 <Particular hazards>. Contact Pfeiffer for spare parts and necessary instructions.</p>	
<p>If a pneumatic actuator with springs must be removed from the valve</p>	<p></p> <p>Caution: Risk of injury Before removing the actuator from the valve, disconnect the signal pressure.</p>	

For malfunctioning actuator units, refer to the actuator instructions.

8 Further information

Contact the address below for the listed <Data sheets> and <Repair instructions> as well as further information.

Pfeiffer Chemie-Armaturenbau GmbH

Hooghe Weg 41 • 47906 Kempen
Telefon: 02152 / 2005-0 • Telefax: 02152 / 1580
E-Mail: vertrieb@pfeiffer-armaturen.com • Internet: www.pfeiffer-armaturen.com